



1989-1991 Grand Wagoneer Rear Windshield Wiper Nozzle Installation

1. Before installing the rear windshield wiper nozzle, be sure your washer hose system is working by seeing if fluid comes out of the open hose.
2. Using a small flathead screwdriver, gently bend tines out on the bottom of the nozzle slightly. This will ease your installation of the nozzle. They are not hard plastic and are made to bend some.



3. Attach the existing hose to the back of the new nozzle.
4. Place nozzle in factory hole with sprayer facing up or down. Slide and press the nozzle to the far right of opening. While still pressing, twist the nozzle to correct position with metal spray nozzle facing tailgate glass.



5. Work nozzle gently towards the left toward the glass to allow the grommet to cover the factory opening. [Click To View Video Tutorial](#).
6. Using a small straight pin or the like, insert into the metal spray nozzle and gently adjust to hit the tailgate glass properly. Quick adjustment with 2 people, about 5 minutes with 1 person.

*Note: If the opening in the C-pillar is rusted or out of spec (Bent), the nozzle tines may not be able to grab.